

1999/2000 BUELL LIGHTNING X1

SERVICE MANUAL

The information in this Service Manual applies
to 1999 and 2000 Buell X1 models.

©COPYRIGHT 1999
BUELL DISTRIBUTION CORPORATION
ALL RIGHTS RESERVED
PART NO. 99490-00Y

MAINTENANCE

1

CHASSIS

2

ENGINE

3

FUEL SYSTEM

4

ELECTRIC STARTER

5

DRIVE/TRANSMISSION

6

ELECTRICAL

7

APPENDIX

INDEX

READERS COMMENTS

The Harley-Davidson Service Communications Department maintains a continuous effort to improve the quality and usefulness of its publications. To do this effectively we need user feedback — your critical evaluation of this manual.

Please comment on this manual's completeness, accuracy, organization, usability and readability.

Did you find errors in this manual?

How can this manual be improved?

Occupation

Name

Dealership

Street

Department

City

State

Zip

1999/2000
Buell X1
Service Manual

Clip out and mail to:
Service Communications Dept.
Harley-Davidson Motor Company
P.O. Box 653
Milwaukee, WI 53201

CUT HERE

FOREWORD

GENERAL

This Service Manual has been prepared with two purposes in mind. First, it will acquaint the user with the construction of the Buell product and assist in the performance of basic maintenance and repair. Secondly, it will introduce to the professional Buell Technician the latest field-tested and factory-approved major repair methods. We sincerely believe that this Service Manual will make your association with Buell products more pleasant and profitable.

HOW TO USE YOUR SERVICE MANUAL

Information is arranged as follows:

- Section 1—Maintenance
- Section 2—Chassis
- Section 3—Engine
- Section 4—Fuel System
- Section 5—Electric Starter
- Section 6—Drive/Transmission
- Section 7—Electrical
- Appendix A—Tools
- Appendix B—Metric Conversions

Use the TABLE OF CONTENTS following this FOREWORD or the INDEX at the back of the book to find the desired subject.

Note that each manual section topic is sequentially numbered in the upper left or right hand corner of the page. The numbering system allows the user to quickly find cross referenced topics by flipping through the pages.

For example, the twelfth topic (CLUTCH) in section one (MAINTENANCE) is listed as:

1.12 CLUTCH

The 1.12 will appear in the upper left or right hand corner of the page.

PREPARATION FOR SERVICE

WARNING

Gasoline is extremely flammable and highly explosive. Always stop the engine when refueling or servicing the fuel system. Do not smoke or allow open flame or sparks near the work site. Inadequate safety precautions may result in personal injury.

Good preparation is very important for efficient service work. A clean work area at the start of each job will allow you to perform the repair as easily and quickly as possible, and will reduce the incidence of misplaced tools and parts. A motorcycle that is excessively dirty should be cleaned before work starts. Cleaning will occasionally uncover sources of trouble. Tools, instruments and any parts needed for the job should be gathered before work is started. Interrupting a job to locate tools or parts is a distraction and causes needless delay. See APPENDIX A—TOOLS for equipment required for special service work.

NOTE

- To avoid unnecessary disassembly, carefully read all relative service information before repair work is started.
- In figure legends, the number which follows the name of a part indicates the quantity necessary for one complete assembly.

SERVICE BULLETINS

In addition to the information presented in this Service Manual, Buell Distribution Corporation will periodically issue Service Bulletins to Buell dealers. Service Bulletins cover interim engineering changes and supplementary information.

USE GENUINE REPLACEMENT PARTS

WARNING

When replacement parts are required, use only genuine Buell parts or parts with equivalent characteristics (which include type, strength and material). Failure to do so may result in product malfunction and possible personal injury.

To ensure satisfactory and lasting repairs, carefully follow the Service Manual instructions and use only genuine Buell replacement parts. This is your assurance that the parts you are using will fit right, operate properly and last longer.

SAFETY DEFINITIONS

Statements in this service manual preceded by the following words are of special significance:

WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

CAUTION

CAUTION without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in serious property damage.

WARNING

- Proper service and repair is important for the safe, reliable operation of all mechanical products. The service procedures recommended and described in this Service Manual are effective methods for performing service operations. Some of these service operations require the use of tools specially designed for the purpose. These special tools should be used when and as recommended. It is important to note that some warnings against the use of specific service methods, which could damage the motorcycle or render it unsafe, are stated in this Service Manual. However, please remember that these warnings are not all-inclusive.
- Since Buell could not possibly know, evaluate or advise the service trade of all possible ways in which service might be performed, or of the possible hazardous consequences of each method, we have not undertaken any such broad evaluation. Accordingly, anyone who uses a service procedure or tool which is not recommended by Buell must first thoroughly satisfy himself that neither his nor the operator's safety will be jeopardized as a result.
- Wear eye protection when using hammers, arbor or hydraulic presses, gear pullers, spring compressors, slide hammers and similar tools. Be especially cautious when using pulling, pressing or compressing equipment. The forces involved can cause parts to fly outward with considerable force, possibly resulting in personal injury.

Buell products are manufactured under one or more of the following U.S. patents – 4776423, 4951774, 4964484, 4989696, 5209319, 5295702, 5303795, 5332246, 5435584.

PRODUCT REFERENCES

WARNING

Follow the directions listed on all products. Carefully read all labels, warnings and cautions before use. Inadequate safety precautions may result in personal injury.

When reference is made in this Service Manual to a specific brand name product, tool or instrument, an equivalent product, tool or instrument may be substituted.

Kent-Moore Products

All tools mentioned in this manual with an "HD", "J" or "B" preface must be ordered through:

Kent-Moore
SPX Corporation
28635 Mound Road
Warren, Michigan 48092-3499
Telephone: 1-800-345-2233

Sealing and Threadlocking Products

LOCTITE PRODUCTS

Some procedures in this Service Manual call for the use of Loctite® products. If you have any questions regarding Loctite product usage or retailer/wholesaler locations, please call Loctite Corp. at 1-800-323-5106.

CONTENTS

All photographs, illustrations and procedures may not necessarily depict the most current model or component, but are based on the latest production information available at the time of publication.

Since product improvement is our continual goal, Buell Distribution Corporation reserves the right to change specifications, equipment or designs at any time without notice and without incurring obligation.

FOREWORD

GENERAL

This Service Manual has been prepared with two purposes in mind. First, it will acquaint the user with the construction of the Buell product and assist in the performance of basic maintenance and repair. Secondly, it will introduce to the professional Buell Technician the latest field-tested and factory-approved major repair methods. We sincerely believe that this Service Manual will make your association with Buell products more pleasant and profitable.

HOW TO USE YOUR SERVICE MANUAL

Information is arranged as follows:

- Section 1—Maintenance
- Section 2—Chassis
- Section 3—Engine
- Section 4—Fuel System
- Section 5—Electric Starter
- Section 6—Drive/Transmission
- Section 7—Electrical
- Appendix A—Tools
- Appendix B—Metric Conversions

Use the TABLE OF CONTENTS following this FOREWORD or the INDEX at the back of the book to find the desired subject.

Note that each manual section topic is sequentially numbered in the upper left or right hand corner of the page. The numbering system allows the user to quickly find cross referenced topics by flipping through the pages.

For example, the twelfth topic (CLUTCH) in section one (MAINTENANCE) is listed as:

1.12 CLUTCH

The 1.12 will appear in the upper left or right hand corner of the page.

PREPARATION FOR SERVICE

WARNING

Gasoline is extremely flammable and highly explosive. Always stop the engine when refueling or servicing the fuel system. Do not smoke or allow open flame or sparks near the work site. Inadequate safety precautions may result in personal injury.

Good preparation is very important for efficient service work. A clean work area at the start of each job will allow you to perform the repair as easily and quickly as possible, and will reduce the incidence of misplaced tools and parts. A motorcycle that is excessively dirty should be cleaned before work starts. Cleaning will occasionally uncover sources of trouble. Tools, instruments and any parts needed for the job should be gathered before work is started. Interrupting a job to locate tools or parts is a distraction and causes needless delay. See APPENDIX A—TOOLS for equipment required for special service work.

NOTE

- *To avoid unnecessary disassembly, carefully read all relative service information before repair work is started.*
- *In figure legends, the number which follows the name of a part indicates the quantity necessary for one complete assembly.*

SERVICE BULLETINS

In addition to the information presented in this Service Manual, Buell Distribution Corporation will periodically issue Service Bulletins to Buell dealers. Service Bulletins cover interim engineering changes and supplementary information.

USE GENUINE REPLACEMENT PARTS

WARNING

When replacement parts are required, use only genuine Buell parts or parts with equivalent characteristics (which include type, strength and material). Failure to do so may result in product malfunction and possible personal injury.

To ensure satisfactory and lasting repairs, carefully follow the Service Manual instructions and use only genuine Buell replacement parts. This is your assurance that the parts you are using will fit right, operate properly and last longer.

TABLE OF CONTENTS

Page No.

Page No.

SECTION 1-MAINTENANCE

1.1 General 1-1

Servicing a New Motorcycle 1-1

Safe Operating Maintenance 1-1

Shop Practices 1-1

Repair Notes 1-1

Safety 1-1

Removing Parts 1-1

Cleaning 1-1

Disassembly and Assembly 1-2

Checking Torques on Fasteners with Lock Patches 1-2

Repair and Replacement Procedures 1-2

Hardware and Threaded Parts 1-2

Wiring, Hoses and Lines 1-2

Instruments and Gauges 1-2

Bearings 1-2

Bushings 1-2

Gaskets 1-2

Lip Type Seals 1-2

O-Rings (Preformed Packings) 1-2

Gears 1-2

Shafts 1-2

Part Replacement 1-2

Cleaning 1-3

Part Protection 1-3

Cleaning Process 1-3

Rust or Corrosion Removal 1-3

Bearings 1-3

Inspecting 1-3

Leak Dye 1-3

Tool Safety 1-3

Air Tools 1-3

Wrenches 1-3

Pliers/Cutters/Prybars 1-3

Hammers 1-3

Punches/Chisels 1-3

Screwdrivers 1-3

Ratchets and Handles 1-4

Sockets 1-4

Storage Units 1-4

1.2 Side Views 1-5

1.3 Fluid Requirements 1-6

General 1-6

United States System 1-6

Metric System 1-6

Steering Head Bearing Grease 1-6

Primary Drive/Transmission Fluid 1-6

Front Fork Oil 1-6

Brake Fluid (1999 Models) 1-6

Brake Fluid (2000 Models) 1-6

Fuel 1-6

Engine Oil 1-6

Recommended Oil Grades (table) 1-6

Regular Maintenance Intervals (table) 1-7

1.4 Battery (1999 Models) 1-11

General 1-11

Inspection 1-11

Storage 1-12

Removal 1-12

Installation 1-12

1.5 Battery (2000 Models) 1-14

General 1-14

Battery Testing 1-14

Voltmeter Test (Table) 1-14

Disconnection and Removal 1-15

Cleaning and Inspection 1-15

Storage 1-15

Removal 1-15

Installation and Connection 1-16

1.6 Engine Lubrication System 1-17

Checking Engine Oil Level 1-17

Recommended Oil Grades (Table) 1-17

Changing Engine Oil and Filter 1-18

1.7 Brakes (1999 Models) 1-19

General 1-19

Bleeding Brakes 1-19

Rear Brake Pedal 1-20

1.8 Brake Pads and Rotors (1999 Models) 1-21

Brake Pads 1-21

Brake Rotors 1-21

Brake Rotor Drive Pins 1-21

Brake Rotor Thickness 1-21

Brake Carrier Lateral Free Play 1-22

Brake Carrier Rotational Free Play 1-22

1.9 Brakes (2000 Models) 1-23

General 1-23

Bleeding Brakes 1-23

Rear Brake Pedal 1-25

1.10 Brake Pads and Rotors (2000 Models)

Brake Pads	1-26
Brake Rotors	1-26
Brake Rotor Thickness	1-26

1.11 Tires and Wheels

Tire Inflation	1-27
Tire Pressures (table)	1-27
Wheel Bearings	1-27

1.12 Clutch

Transmission Fluid	1-28
Adjustment	1-29

1.13 Rear Belt Deflection

Inspection	1-30
Adjustment	1-31
Axle Alignment	1-31
Deflection Adjustment	1-31

1.14 Rear Belt and Sprocket

General	1-32
Cleaning	1-32
Inspection	1-32
Rear Sprocket	1-32
Drive Belt	1-32
Drive Belt Wear Analysis (table)	1-33

1.15 Primary Chain

Inspection	1-34
Primary Chain Tension (table)	1-34
Adjustment	1-35

1.16 Preload Adjustment

General	1-36
Adjustment	1-36

1.17 Suspension

Adjustment	1-38
Front Fork Rebound	1-38
Front Fork Compression	1-38
Rear Shock Rebound	1-38
Rear Shock Compression	1-38

1.18 Front Fork Oil

Fork Oil Change	1-39
Fork Oil (table)	1-39

1.19 Steering Head Bearings

Inspection	1-40
Lubrication	1-40
Adjustment	1-41

1.20 Spark Plugs

Inspection	1-42
------------------	------

1.21 Air Cleaner Filter

Removal	1-43
Installation	1-43

1.22 Throttle Cables

Adjustment	1-44
Idle Adjustment	1-44

1.23 Ignition Timing

Inspection	1-45
Static Timing	1-45

1.24 Handlebars

Inspection	1-47
Adjustment	1-47

1.25 Headlamp

Inspection	1-48
Adjustment	1-48

1.26 Storage

General	1-49
Removal from Storage	1-49

	Page No.
1.27 Troubleshooting	1-50
General	1-50
Engine	1-50
Starter Motor Does Not Operate	1-50
Engine Turns Over But Does Not Start	1-50
Starts Hard	1-50
Starts But Runs Irregularly or Misses	1-50
Spark Plug Fouls Repeatedly	1-51
Pre-Ignition or Detonation (Knocks or Pings)	1-51
Overheating	1-51
Valve Train Noise	1-51
Excessive Vibration	1-51
Engine Lubrication System	1-51
Oil Does Not Return To Oil Tank	1-51
Engine Uses Too Much Oil/Smokes	1-51
Engine Leaks Oil From Cases, Etc.	1-51
Electrical System	1-51
Alternator Does Not Charge	1-51
Alternator Charge Rate Is Below Normal	1-51
Fuel	1-51
Fuel System Floods	1-51
Poor Fuel Economy	1-51
Transmission	1-51
Shifts Hard	1-51
Jumps Out of Gear	1-51
Clutch	1-52
Slips	1-52
Drags or Does Not Release	1-52
Chatters	1-52
Chassis	1-52
Irregular/Inadequate Brake Action	1-52
Handling Irregularities	1-52

SECTION 2-CHASSIS

2.1 Specifications	2-1
Dimensions	2-1
Weight	2-1
Capacities	2-1
Tire and Position	2-1
Torque Values	2-1
2.2 Tire Specifications	2-4
General	2-4
Tire Fitment-Cast Wheels (table)	2-4
Tire Fitment-P/M Wheels (table)	2-4
2.3 Vehicle Identification Number	2-5
General	2-5
2.4 Wheels	2-6
General	2-6
Troubleshooting	2-6
Wheel Service (table)	2-6

2.5 Front Wheel (1999 Models)	2-8
Removal	2-8
Disassembly	2-8
Cleaning, Inspection and Repair	2-8
Assembly	2-9
Installation	2-10
2.6 Front Wheel (2000 Models)	2-11
Model Year Change	2-11
Removal	2-11
Disassembly	2-11
Cleaning and Inspection	2-11
Assembly	2-12
Installation	2-13
2.7 Rear Wheel	2-14
Removal	2-14
Disassembly	2-15
Cleaning, Inspection and Repair	2-15
Assembly	2-15
Installation	2-15
2.8 Checking Cast Rim Runout	2-17
General	2-17
Rim Lateral Runout	2-17
Rim Radial Runout	2-17
Wheel Runout (table)	2-17
2.9 Tires	2-18
Model Year Change	2-18
General	2-18
Removal	2-18
Cleaning and Inspection	2-18
Installation	2-19
Checking Tire Lateral Runout	2-19
Checking Tire Radial Runout	2-19
Adjustment	2-20
Wheel Balancing	2-20
2.10 Brakes (1999 Models)	2-21
General	2-21
Brake Troubleshooting (table)	2-21
2.11 Front Brake Master Cylinder (1999 Models)	2-22
Removal	2-22
Disassembly	2-22
Cleaning, Inspection and Repair	2-23
Assembly	2-23
Installation	2-24

2.12 Front Brake Caliper (1999 Models)

Removal	2-25
Disassembly	2-25
Cleaning, Inspection and Repair	2-26
Assembly	2-26
Installation	2-27

2.13 Front Brake Line (1999 Models)

Removal	2-29
Installation	2-29

2.14 Rear Brake Master Cylinder (1999 Models)

Removal	2-31
Disassembly	2-31
Cleaning, Inspection and Repair	2-32
Assembly	2-32
Installation	2-32

2.15 Rear Brake Caliper (1999 Models)

Removal	2-34
Disassembly	2-34
Cleaning, Inspection and Repair	2-34
Assembly	2-35
Installation	2-35

2.16 Rear Brake Line and Switch (1999 Models)

Removal	2-37
Installation	2-38

2.17 Brakes (2000 Models)

General	2-40
Brake Troubleshooting (table)	2-41

2.18 Front Brake Master Cylinder (2000 Models)

Removal	2-42
Disassembly	2-42
Cleaning and Inspection	2-43
Assembly	2-43
Installation	2-44

2.19 Front Brake Caliper (2000 Models)

Removal	2-45
Disassembly	2-45
Cleaning and Inspection	2-46
Assembly	2-46
Installation	2-46

2.20 Front Brake Line (2000 Models)

Removal	2-48
Installation	2-48

2.21 Rear Brake Master Cylinder (2000 Models)

Removal	2-50
Disassembly	2-50
Cleaning and Inspection	2-51
Assembly	2-51
Installation	2-51

2.22 Rear Brake Caliper (2000 Models)

Removal	2-53
Disassembly	2-53
Cleaning and Inspection	2-53
Assembly	2-54
Installation	2-54

2.23 Rear Brake Line and Switch (2000 Models)

Removal	2-56
Installation	2-57

2.24 Front Fork

General	2-60
Removal	2-60
Disassembly	2-60
Cleaning, Inspection and Repair	2-62
Assembly	2-62
Installation	2-64

2.25 Fork Stem and Bracket Assembly

Removal/Disassembly	2-65
Cleaning, Inspection and Repair	2-65
Assembly/Installation	2-65

2.26 Steering Head Lock

Removal	2-67
Installation	2-67

2.27 Swingarm

Removal	2-69
Disassembly	2-70
Cleaning/Inspection	2-70
Assembly	2-71
Installation	2-71

	Page No.		Page No.
2.28 Rear Shock Absorber	2-74	2.36 Footrests (1999 Models)	2-90
Removal	2-74	Removal	2-90
Installation	2-74	Installation	2-90
2.29 Suspension Theory	2-76	2.37 Footrests (2000 Models)	2-91
Definitions	2-76	Removal	2-91
Damping	2-76	Installation	2-91
Compression	2-76	2.38 Sprocket Cover	2-92
Rebound	2-76	Removal/Disassembly	2-92
Vehicle Sag	2-76	Assembly/Installation	2-92
Rider Sag	2-76	2.39 Front Fender	2-93
Preload	2-76	Removal/Installation	2-93
General	2-76	2.40 Rear Fender	2-94
2.30 Suspension Adjustments	2-77	Removal	2-94
Spring Preload	2-77	Installation	2-94
Adjustments	2-77	2.41 Belt Guards	2-95
Troubleshooting	2-77	Removal	2-95
General Suspension Problems (table)	2-77	Installation	2-95
Rear Suspension Problems (table)	2-78	2.42 Chin Fairing	2-96
Front Suspension Problems (table)	2-78	Removal	2-96
Rider Suspension Preferences (table)	2-79	Installation	2-96
2.31 Throttle Control	2-80	2.43 Fuel Tank Cover	2-97
Model Year Change	2-80	Model Year Change	2-97
Removal/Disassembly	2-80	Removal	2-97
Cleaning, Inspection and Repair	2-80	Installation	2-97
Assembly/Installation	2-80	2.44 Air Scoop	2-98
2.32 Clutch Control	2-82	Removal	2-98
Adjustment	2-82	Installation	2-98
Removal/Disassembly	2-82	2.45 Trunk	2-99
Clutch Cable-Lower	2-82	Removal	2-99
Clutch Hand Control	2-82	Installation	2-99
Assembly/Installation	2-83	2.46 Tail Section	2-100
Clutch Cable-Lower	2-83	Removal	2-100
Clutch Hand Control	2-83	Cleaning	2-100
2.33 Instrument Support	2-84	Disassembly	2-100
Removal	2-84	Assembly	2-102
Installation	2-84	Installation	2-102
2.34 Handlebars	2-85	2.47 Windscreen	2-103
Removal	2-85	Removal	2-103
Installation	2-85	Installation	2-103
2.35 Exhaust System	2-86		
Removal/Disassembly	2-86		
Muffler	2-86		
Exhaust Header	2-86		
Assembly/Installation	2-88		
Muffler	2-88		
Exhaust Header	2-89		

	Page No.
2.48 Seat (1999 Models)	2-104
Removal	2-104
Installation	2-104
Attachment Points	2-104
2.49 Seat (2000 Models)	2-105
Model Year Change	2-105
Removal	2-105
Installation	2-105
Attachment Points	2-105
2.50 Side Stand	2-106
Model Year Change	2-106
General	2-106
Removal/Disassembly	2-106
Assembly/Installation	2-106

SECTION 3-ENGINE

3.1 Specifications	3-1
General	3-1
Camshaft Specifications	3-1
Engine Ignition Specifications	3-1
Service Wear Limits	3-1
Torque Values	3-4
3.2 Engine	3-5
Model Year Change	3-5
General	3-5
Cylinder	3-5
Crankcase	3-5
Gearcase	3-5
Fuel	3-5
Gasoline/alcohol Blends	3-5
Lubrication	3-5
Adjustment/Testing	3-6
General	3-6
Compression Test Procedure	3-6
Compression Test Results (table)	3-6
Cylinder Leakage Test	3-7
Diagnosing Smoking Engine/ High Oil Consumption	3-7
Air Leakage Test (table)	3-7
3.3 Stripping Motorcycle For Engine Repair	3-8
Disassembling Engine for Cylinder Head Repair	3-8
Engine Crankcase Replacement or Complete Engine Removal	3-8
3.4 Installing The Engine	3-10
Engine Crankcase Installation	3-10
Engine Installation After Cylinder Head Repair	3-11

3.5 Cylinder Head	3-12
Removal	3-12
Disassembly	3-14
Cleaning, Inspection and Repair	3-15
Rocker Arms and Bushings	3-16
Replacing Valve Guides	3-17
Valve Stem Clearances (table)	3-17
Grinding Valve Faces and Seats	3-18
Neway Valve Seat Cutters (table)	3-18
Replacing Valve Seats	3-19
Lapping Valve Faces and Seats	3-19
Assembly	3-20
Installation	3-21
Push Rod Selection (table)	3-21
Lower Rocker Box Hardware (table)	3-22
3.6 Cylinder and Piston	3-23
Removal/Disassembly	3-23
Cleaning, Inspection and Repair	3-24
Checking Gasket Surface	3-24
Measuring Cylinder Bore	3-25
Cylinder Bore Service Wear Limits (table)	3-25
Measuring Piston	3-26
Fitting Cylinder to Piston	3-26
Boring and Honing Cylinder	3-26
Fitting Piston Rings	3-26
Final Cylinder Bore Sizes (table)	3-26
Connecting Rod Bushing	3-28
Assembly/Installation	3-29
3.7 Lubrication System	3-30
Checking and Adding Oil	3-30
Changing Oil and Filter	3-30
Winter Lubrication	3-30
3.8 Oil Hose Routing	3-31
General	3-31
3.9 Oil Tank	3-32
Removal/Disassembly	3-32
Assembly/Installation	3-32
3.10 Oil Pressure Indicator Switch	3-33
General	3-33
Oil Pressure Signal Light	3-33
Oil Pressure	3-33
Troubleshooting Oil Pressure Signal Light (table)	3-33
3.11 Crankcase Breathing System	3-34
General	3-34

3.12 Oiling System (Color Foldout)..... 3-35

3.13 Oil Pump..... 3-36

General	3-36
Removal/Disassembly	3-37
Cleaning, Inspection and Repair	3-38
Assembly/Installation	3-38

3.14 Oil Filter Mount..... 3-39

General	3-39
Disassembly	3-39
Cleaning/Inspection	3-39
Assembly	3-39

3.15 Valve Tappets (1999 Models)..... 3-40

General	3-40
Removal	3-40
Cleaning/Inspection	3-40
Installation	3-41

3.16 Hydraulic Lifters (2000 Models)..... 3-42

General	3-42
Removal	3-42
Cleaning/Inspection	3-42
Installation	3-43

3.17 Gearcase Cover and Cam Gears (1999 Models)..... 3-44

General	3-44
Removal/Disassembly	3-44
Cleaning, Inspection and Repair	3-45
Cam and Pinion Gear Identification, Inspection, and Selection	3-45
Cam/Pinion Gear Color Code & Diameter (table)	3-46
Bushing Inspection and Removal	3-47
Bushing Installation	3-47
Gear Shaft Specifications (table)	3-47
Bushing Reaming	3-48
Assembly/Installation	3-50

3.18 Gearcase Cover and Cam Gears (2000 Models)..... 3-52

Model Year Change.....	3-52
General	3-52
Removal/Disassembly	3-53
Cleaning and Inspection	3-53

Cam and Pinion Gear Identification, Inspection, and Selection	3-53
Cam/Pinion Gear Color Code & Diameter (table)	3-54
Bushing Inspection and Removal	3-55
Bushing Installation	3-55
Gear Shaft Specifications (table)	3-55
Bushing Reaming	3-56
Assembly/Installation	3-58

3.19 Crankcase (1999 Models)..... 3-60

General	3-60
Adjustment/Testing	3-60
Flywheel End Play	3-60
Flywheel End Play Spacers (table)	3-60
Disassembly	3-61
Crankcase Halves	3-61
Flywheels	3-63
Cleaning/Inspection	3-63
Replacing Flywheel Washers	3-65
Lapping Connecting Rod Races	3-65
Fitting Rod Bearings	3-66
Fitting Sprocket Bearings	3-67
Fitting Pinion Bearings	3-67
Race Diameter and Crank Pin Size (table)	3-67
Connecting Rod Specifications (table)	3-67
Pinion Shaft Bearing Selection (table)	3-70
Lapping Engine Main Bearing Races	3-71
Assembly	3-71
Flywheels	3-71
Crankcase Halves	3-73

3.20 Crankcase (2000 Models)..... 3-77

Model Year Change	3-77
General	3-77
Adjustment/Testing	3-77
Flywheel End Play	3-77
Flywheel End Play Shims (table)	3-77
Gearshaft Bearings (table)	3-77
Disassembly	3-78
Crankcase Halves	3-78
Flywheel/Connecting Rod Assembly	3-81
Cleaning/Inspection	3-81
Flywheel/Connecting Rod Assembly	3-81
Fitting Sprocket Bearings	3-81
Fitting Pinion Bearings	3-81
Race Diameter and Crank Pin Size (table)	3-82
Pinion Shaft Bearing Selection (table)	3-85
Lapping Engine Main Bearing Races	3-85
Assembly	3-85
Crankcase Halves	3-85

SECTION 4-FUEL SYSTEM

4.1 Dynamic Digital Fuel Injection

Introduction	4-1
General	4-1
For More Information	4-1
Troubleshooting	4-1
Fuel Injection Components	4-1

4.2 Diagnostic Introduction

System Problems	4-3
No Start	4-3
Poor Performance	4-3
Check Engine Lamp	4-3
Resolving Problems	4-3

4.3 Checking For Trouble Codes

Model Year Change	4-4
Check Engine Lamp	4-4
Code Types	4-5
Current	4-5
Historic	4-5
Functional	4-5
Retrieving Trouble Codes	4-5
Multiple Trouble Codes	4-5

4.4 Scanalyzer

Scanalyzer Diagnostics	4-6
Data Link Connector	4-6
Scanalyzer Cartridge	4-6
Installation	4-6
Usage	4-8
Checking Codes	4-8
Clearing Codes	4-8
Removal	4-8

4.5 Check Engine Lamp Diagnostics

Activation	4-9
Clearing Codes	4-10

4.6 Breakout Box

General	4-11
Installation	4-11
Removal	4-11

4.7 Wiggle Test

General	4-12
Procedure	4-12
Using Scanalyzer	4-12
Using DVOM	4-12

4.8 Initial Diagnostic Check

General	4-13
Diagnostic Notes	4-13
Scanalyzer Icon	4-13
Circuit Diagram/Wire Harness Connector Table	4-13
Job/Time Code Values	4-13
Initial Diagnostics	4-13
General Information	4-13
Diagnostic Tips	4-13
Diagnostic Notes	4-13
Typical Scan Values (table)	4-14
Engine Starts Hard (table)	4-14
Engine Performance Problems (table)	4-14
Engine Exhaust Emits Black Smoke (table)	4-14
Trouble Codes and Fault Conditions (table)	4-15
Wire Harness Connectors (table)	4-16
Diagnostic Check (Part 1 of 2) (flow chart)	4-17
Diagnostic Check (Part 2 of 2) (flow chart)	4-18

4.9 Check Engine Lamp Not Illuminated at Key ON

General	4-19
Diagnostics	4-19
Diagnostic Tips	4-19
Diagnostic Notes	4-19
Wire Harness Connectors (table)	4-20
Test (flow chart)	4-21

4.10 Check Engine Lamp On Continuously

General	4-22
Diagnostics	4-22
Diagnostic Notes	4-22
Wire Harness Connectors (table)	4-23
Test (flow chart)	4-24

4.11 Engine Cranks But Will Not Start

General	4-25
Diagnostics	4-25
Diagnostic Notes	4-25
Wire Harness Connectors (table)	4-25
Test (Part 1 of 3) (flow chart)	4-27
Test (Part 2 of 3) (flow chart)	4-28
Test (Part 3 of 3) (flow chart)	4-29

4.12 No ECM Power

General	4-30
Diagnostics	4-30
Diagnostic Notes	4-30
Wire Harness Connectors (table)	4-31
No ECM Power (flow chart)	4-32

4.13 Fuel Pressure Test	4-33
Inspection	4-33
Diagnostics	4-34
Diagnostic Notes	4-34
Wire Harness Connectors (table)	4-35
Test (Part 1 of 2) (flow chart)	4-36
Test (Part 2 of 2) (flow chart)	4-37
4.14 Idle Speed Control	4-38
Adjustments	4-38
4.15 Misfire	4-39
General	4-39
Misfire At Idle or Under Load	4-39
Diagnostics	4-39
Diagnostic Notes	4-39
Spark Plug Cables (table)	4-39
Wire Harness Connectors (table)	4-40
Test (Part 1 of 2) (flow chart)	4-41
Test (Part 2 of 2) (flow chart)	4-42
4.16 Trouble Code 11	4-43
General	4-43
Throttle Position Sensor	4-43
Diagnostics	4-43
Diagnostic Tips	4-43
Scanalyzer Notes	4-43
Diagnostic Notes	4-48
Wire Harness Connectors (table)	4-44
Code 11 Test (Part 1 of 2) (flow chart)	4-45
Code 11 Test (Part 2 of 2) (flow chart)	4-46
4.17 Trouble Code 13	4-47
General	4-47
Oxygen Sensor (O2)	4-47
Diagnostics	4-47
Diagnostic Tips	4-47
Diagnostic Notes	4-47
Wire Harness Connectors (table)	4-48
Code 13 Test (Part 1 of 3) (flow chart)	4-49
Code 13 Test (Part 2 of 2) (flow chart)	4-50
Code 13 Test (Part 3 of 3) (flow chart)	4-51
4.18 Trouble Code 14	4-52
General	4-52
Engine Temperature Sensor	4-52
Diagnostics	4-52
Diagnostic Tips	4-52
Diagnostic Notes	4-52
Scanalyzer Notes	4-52
Engine Temperature Sensor	
Specifications (table)	4-52
Wire Harness Connectors (table)	4-53
Code 14 Test (Part 1 of 2) (flow chart)	4-54
Code 14 Test (Part 2 of 2) (flow chart)	4-55

4.19 Trouble Code 15	4-56
General	4-56
Intake Air Temperature Sensor	4-56
Diagnostics	4-56
Diagnostic Tips	4-56
Diagnostic Notes	4-56
Scanalyzer Notes	4-56
Intake Air Temperature Sensor	
Specifications (table)	4-56
Wire Harness Connectors (table)	4-57
Code 15 Test (Part 1 of 2) (flow chart)	4-58
Code 15 Test (Part 2 of 2) (flow chart)	4-59
4.20 Trouble Code 16	4-60
General	4-60
Battery Voltage	4-60
Diagnostics	4-60
Diagnostic Notes	4-60
Scanalyzer Notes	4-60
Wire Harness Connectors (table)	4-61
Code 16 Test (Part 1 of 2) (flow chart)	4-62
Code 16 Test (Part 2 of 2) (flow chart)	4-63
4.21 Trouble Codes 23 and 32	4-64
General	4-64
Front Fuel Injector (Code 23) And Rear Fuel Injector	
(Code 32)	4-64
Diagnostics	4-64
Diagnostic Notes	4-64
Scanalyzer Notes	4-64
Wire Harness Connectors (table)	4-65
Code 23/32 Test (Part 1 of 2) (flow chart)	4-66
Code 23/32 Test (Part 2 of 2) (flow chart)	4-67
4.22 Trouble Codes 24 and 25	4-68
General	4-68
Front Ignition Coil (Code 24) And Rear Ignition Coil	
(Code 25)	4-68
Diagnostics	4-68
Diagnostic Notes	4-68
Scanalyzer Notes	4-68
Wire Harness Connectors (table)	4-69
Code 24/25 Test (flow chart)	4-70
4.23 Trouble Code 33	4-71
General	4-71
Fuel Pump	4-71
Diagnostics	4-71
Diagnostic Notes	4-71
Scanalyzer Notes	4-71
Wire Harness Connectors (table)	4-72
Code 33 Test (flow chart)	4-73

4.24 Trouble Code 35..... 4-74

General	4-74
Tachometer	4-74
Diagnostics	4-74
Diagnostic Notes	4-74
Wire Harness Connectors (table)	4-75
Code 35 Test (flow chart)	4-76

4.25 Trouble Code 44..... 4-77

General	4-77
Bank Angle Sensor	4-77
Diagnostics	4-77
Diagnostic Notes	4-77
Wire Harness Connectors (table)	4-78
Code 44 Test (Part 1 of 2) (flow chart)	4-79
Code 44 Test (Part 2 of 2) (flow chart)	4-80

4.26 Trouble Codes 52, 53, 54 and 55..... 4-81

General	4-81
ECM Failure	4-81

4.27 Trouble Code 56..... 4-82

General	4-82
Cam Sync Failure	4-82
Diagnostics	4-82
Diagnostic Notes	4-82
Wire Harness Connectors (table)	4-83
Code 56 (Part 1 of 2) (flow chart)	4-84
Code 56 (Part 2 of 2) (flow chart)	4-85

4.28 Electronic Control Module... 4-86

Removal	4-86
Installation	4-86

4.29 Cam Position Sensor and Rotor..... 4-88

Removal	4-88
Installation	4-91

4.30 Ignition Coil..... 4-92

Troubleshooting	4-92
Ignition Coil Primary Circuit Test	4-92
Ignition Coil Secondary Circuit Test	4-92
Test Results	4-92
Ignition Coil Substitution	4-92
Removal	4-93
Installation	4-93

4.31 Sensors..... 4-94

General	4-94
Oxygen Sensor	4-94
Removal	4-94
Installation	4-94
Engine Temperature Sensor	4-94
Model Year Change.....	4-94
Removal	4-94
Installation	4-94

4.32 Bank Angle Sensor..... 4-95

Removal	4-95
Installation	4-95

4.33 Throttle Position Sensor..... 4-96

Removal	4-96
Installation	4-96
Calibration	4-96

4.34 Fuel Tank..... 4-97

Removal	4-97
Disassembly/Assembly	4-98
Cleaning, Inspection and Repair	4-98
Installation	4-99
Fuel Tank Pressure Test	4-99

4.35 Fuel Tank Vent Valve..... 4-100

Model Year Change.....	4-100
General.....	4-100
Removal	4-100
Installation	4-100

4.36 Inline Fuel Filter..... 4-102

Model Year Change.....	4-102
General	4-102
Removal/Installation	4-102

4.37 Fuel Pump..... 4-103

Removal	4-103
Repair	4-103
Fuel Pump Replacement	4-103
Fuel Pressure Regulator Replacement	4-104
Low Fuel Level Sensor Replacement	4-104
Installation	4-104

4.38 Throttle Body and Manifold 4-105

General	4-105
Removal	4-105
Repair	4-106
Throttle Position Sensor	4-106
Fuel Injectors	4-106
Installation	4-107

4.39 Air Cleaner	4-109
Removal	4-109
Inspection	4-109
Installation	4-109

4.40 Evaporative Emissions Control-California Models

General	4-111
Troubleshooting	4-111
Removal	4-112
Vent Valve	4-112
Canister	4-112
Installation	4-112
Vent Valve	4-112
Canister	4-113
Hose Routing	4-113
Throttle Body Manifold	4-113
Canister Hose Routings	4-113

SECTION 5-ELECTRIC STARTER

5.1 Specifications	5-1
Starter	5-1
Service Wear Limits	5-1
Torque Values	5-1
5.2 Electric Starter System	5-2
General	5-2
Wiring Diagrams	5-2
Starter Relay	5-2
Starter Interlock	5-2
Operation	5-2
Troubleshooting (table)	5-4
5.3 Starting System Diagnosis	5-6
5.4 Starter Activation Circuits	5-8
5.5 Diagnostics/ Troubleshooting	5-9
General	5-9
Voltage Drops	5-9
5.6 Starter System Testing	5-11
"On Motorcycle" Tests	5-11
Starter Relay Test	5-11
Starter Current Draw Test	5-11

5.7 Starter	5-12
Removal	5-12
Testing Assembled Starter	5-12
Free Running Current Draw Test	5-12
Starter Solenoid	5-13
Solenoid Pull-in Test	5-13
Solenoid Hold-in Test	5-13
Solenoid Return Test	5-13
Disassembly, Inspection and Repair	5-14
Assembly	5-17
Installation	5-18

5.8 Starter Solenoid	5-19
General	5-19
Disassembly	5-19
Assembly	5-19

SECTION 6-DRIVE/TRANSMISSION

6.1 Specifications	6-1
Transmission	6-1
Transmission Gear Ratios	6-1
Primary Drive	6-1
Final Drive	6-1
Clutch Plate Thickness	6-1
Torque Values	6-2
6.2 Primary Chain	6-3
General	6-3
Adjustment/Lubrication	6-3
Removal	6-3
Primary Cover	6-3
Primary Chain Adjuster	6-4
Installation	6-4
Primary Chain Adjuster	6-4
Primary Cover	6-5
6.3 Secondary Drive Belt	6-6
General	6-6
Removal	6-6
Installation	6-7
6.4 Clutch Release Mechanism	6-8
Adjustment	6-8
Disassembly	6-8
Cleaning, Inspection and Repair	6-8
Assembly	6-9

6.5 Primary Drive/Clutch 6-10

General	6-10
Clutch Troubleshooting (table)	6-10
Removal/Disassembly	6-11
Clutch Pack	6-11
Primary Chain/Drive	6-13
Inspection/Repair	6-14
Assembly	6-15
Clutch Pack	6-15
Primary Drive	6-15
Installation	6-16

6.6 Transmission 6-17

Model Year Change	6-17
General	6-17
Lubrication	6-17

6.7 Transmission Case 6-19

General	6-19
Removal	6-19
Cleaning, Inspection and Repair	6-20
Neutral Indicator Switch	6-20

6.8 Shifter Forks and Drum 6-21

Disassembly	6-21
Cleaning, Inspection and Repair	6-21
Assembly	6-22

6.9 Mainshaft and Countershaft 6-24

Disassembly	6-24
Cleaning, Inspection and Repair	6-27
Assembly	6-27

6.10 Main Drive Gear 6-30

Removal	6-30
Disassembly	6-31
Assembly	6-31
Installation	6-31

6.11 Access Door Bearings 6-32

Removal	6-32
Mainshaft and Countershaft Bearings	6-32
Shift Drum Bushing	6-32
Installation	6-32
Mainshaft and Countershaft Bearings	6-32
Shift Drum Bushing	6-32

6.12 Right Transmission Case Bearings 6-33

Removal	6-33
Installation	6-33
Mainshaft 5th Gear Ball Bearing	6-33
Countershaft Needle Bearing	6-33
Shift Drum Needle Bearing	6-33

6.13 Transmission Installation and Shifter Pawl Adjustment 6-34**SECTION 7-ELECTRICAL****7.1 Specifications** 7-1

Battery	7-1
Spark Plugs	7-1
Alternator	7-1
Regulator	7-1
Ignition Coil Resistance	7-1
Electrical System	7-1
Bulb Chart	7-1
Torque Specifications	7-2

7.2 Ignition System 7-3

General	7-3
Troubleshooting	7-3

7.3 Ignition/Headlamp Key Switch 7-5

General	7-5
Removal	7-5
Ignition Key Switch Positions (table)	7-5
Indicator Markers (table)	7-5
Installation	7-6

7.4 Spark Plug Cables 7-7

General	7-7
Removal	7-7
Inspection	7-7
Installation	7-7

7.5 Starter Interlock 7-8

Model Year Change	7-8
General	7-8
Starter Circuit	7-8
Ignition Circuit	7-8
Starter Interlock Troubleshooting (table)	7-8
Diagnostics	7-9
Ignition Test (flow chart)	7-10
Starter Test (Part 1 of 2) (flow chart)	7-10
Starter Test (Part 2 of 2) (flow chart)	7-11
Testing/Replacement	7-13
Side Stand Switch	7-13
Clutch Switch	7-13
Ignition Relay	7-14
Starter Relay	7-14
Ignition Fuse	7-14
Diodes	7-14
Main Circuit Breaker	7-14

7.6 Charging System	7-15	7.12 Headlamp	7-34
General	7-15	Removal/Disassembly	7-34
Alternator	7-15	Removal	7-34
Voltage Regulator	7-15	Headlamp Bulb	7-34
Troubleshooting	7-15	Headlamp Housing and Brackets	7-34
Battery	7-15	Installation	7-35
Wiring	7-15	Headlamp Bulb	7-35
Voltage Regulator Inspection	7-15	Headlamp Housing and Brackets	7-35
Testing	7-18	7.13 Tail Lamp	7-36
Voltage Regulator Bleed Test	7-18	Removal/Disassembly	7-36
Milliampere Draw Test	7-18	Assembly/Installation	7-36
Total Current Draw Test	7-18	7.14 Turn Signals	7-37
Current and Voltage Output Test	7-19	Removal	7-37
Voltage Output Test	7-19	Bulbs	7-37
Stator Check	7-19	Front	7-37
AC Output Check	7-20	Rear	7-37
7.7 Alternator	7-21	Installation	7-37
Removal/Disassembly	7-21	Front	7-37
Rotor	7-21	Rear	7-38
Stator	7-21	7.15 Turn Signal Flasher	7-39
Cleaning, Inspection and Repair	7-22	Removal	7-39
Assembly/Installation	7-22	Installation	7-39
7.8 Voltage Regulator	7-23	7.16 Handlebar Switches	7-40
General	7-23	Removal	7-40
Removal	7-23	Right Side	7-40
Installation	7-23	Left Side	7-40
7.9 Battery (1999 Models)	7-24	Installation	7-41
General	7-24	Right Side	7-41
Testing	7-24	Left Side	7-41
Open Circuit Voltage Test	7-24	7.17 Speedometer Sensor	7-43
Charging Rates (table)	7-24	Removal	7-43
Load Test	7-25	Installation	7-43
Charging Battery	7-25	7.18 Speedometer	7-44
7.10 Battery Cables (1999 Models)	7-26	General	7-44
Removal	7-26	Removal	7-44
Installation	7-26	Installation	7-45
7.11 Battery (2000 Models)	7-28	7.19 Tachometer	7-46
General	7-28	General	7-46
Battery Testing	7-28	Removal	7-46
Voltmeter Test	7-28	Installation	7-47
Disconnection and Removal	7-29	7.20 Speedometer Performance Check	7-48
Cleaning and Inspection	7-29	General	7-48
Battery Charging	7-29	Testing	7-48
Safety Precautions	7-29	Speedometer Operation Test	7-48
Charging Battery	7-29	Speedometer Test Frequency (table)	7-48
Battery Charging Rates and Times (table)	7-30	Speedometer Needle Sweep Test	7-49
Battery Testing	7-30	Speedometer Sensor Test	7-49
Load Test	7-30	Speedometer Test: Chart 1 (flowchart)	7-50
Battery Cable Routing	7-31	Speedometer Test: Chart 2A (flowchart)	7-51
Battery Installation and Connection	7-31	Speedometer Test: Chart 2B (flow chart)	7-52
Battery Stocking and Selling	7-33		

7.21 Tachometer Performance Check	7-53
General	7-53
Testing	7-53
Operation Test	7-53
Tachometer Accuracy Tolerances (table)	7-53
Sweep Test	7-53
7.22 Horn	7-54
Removal	7-54
Installation	7-54
Troubleshooting	7-55
7.23 Neutral Indicator Switch	7-56
General	7-56
Testing	7-56
Removal/Installation	7-56
7.24 Fuses and Circuit Breakers	7-57
General	7-57
Fuses	7-57
Master Circuit Breaker	7-57
7.25 Electrical Connectors	7-58
General	7-58
Electrical Connectors (Table)	7-58
7.26 Deutsch Electrical Connectors	7-59
General	7-59
Removing/Installing Sockets	7-59
Removing/Installing Pins	7-59
Assembly/Installation	7-59
Crimping Instructions	7-60
7.27 Amp Multilock Electrical Connectors	7-61
Removing Socket/Pin Terminals	7-61
Installing Socket/Pin Terminals	7-62
Crimping Instructions	7-63
Wiring Diagram	7-65

APPENDIX

Appendix A-Tools	A-1
Appendix B-Metric Conversions	B-1