

INDEX

	Page No.		Page No.
A		Battery (2000 Models)	
AC Output Check	7-20	Cable Routing	7-31
Access Door Bearings		Charging	7-29
Installation	6-32	Cleaning and Inspection	1-15
Removal	6-32	General	7-28
Adding Engine Oil	3-30	Installation and Connection	1-16
Air Cleaner Filter		Load Test	7-30
Installation	1-43	Maintenance	1-14
Maintenance	1-43	Open Circuit Voltage Test	7-24
Removal	1-43	Removal	1-15
Air Cleaner		Specifications	7-1
Inspection	4-109	Stocking and Selling	7-33
Installation	4-109	Storage	1-15
Removal	4-109	Testing	7-28
Air Scoop	2-98	Troubleshooting	7-15
Installation	2-98	Bearing Grease, Steering Head	1-6
Removal	2-98	Bearing Selection (1999 Models)	3-70
Air Tools, Safety	1-3	Bearing Selection (2000 Models)	3-85
Alternator		Belt Guards	2-95
Assembly/Installation	7-22	Installation	2-95
Cleaning	7-22	Removal	2-95
Removal/Disassembly	7-21	Boring and Honing, Cylinder	3-26
Specifications	7-1	Brake Fluid	1-6
Amp Multilock Electrical Connectors	7-61	Brake Pads and Rotors (1999 Models)	1-21
Angle Sensor-See Bank Angle Sensor	4-95	Brake Pads and Rotors (2000 Models)	1-26
Axle Alignment	1-31	Brake Rotor, Drive Pins (1999 Models)	1-21
B		Brakes (1999 Models)	
Bank Angle Sensor	4-95	Bleeding	1-19
Installation	4-95	General	2-21
Removal	4-95	Maintenance	1-19
BAS-See Bank Angle Sensor	4-95	Troubleshooting (table)	2-21
Battery Cables (1999 Models)	7-26	Brakes (2000 Models)	
Installation	7-26	Bleeding	1-23
Removal	7-26	General	2-40
Battery Charging (1999 Models - table)	7-24	Maintenance	1-23
Battery Charging (2000 Models - table)	7-30	Troubleshooting (table)	2-41
Battery (1999 Models)		Breakout Box	4-11
Charging	7-24	Installation	4-11
General	7-24	Removal	4-11
Inspection	1-11	Breathing System, Crankcase	3-34
Installation	1-12	Bulbs, Turn Signals	7-37
Load Test	7-25	Bushing (1999 Models)	
Maintenance	1-11	Inspection/Removal	3-47
Open Circuit Voltage Test	7-24	Installation	3-47
Removal	1-12	Reaming	3-48
Specifications	7-1	Bushing (2000 Models)	
Storage	1-12	Inspection/Removal	3-55
Testing	7-24	Installation	3-55
Troubleshooting	7-15	Reaming	3-56
C		C	
		Calibration, TP Sensor	4-96
		Cam and Pinion Gear Identification (1999 Models)	3-45
		Cam and Pinion Gear Identification (2000 Models)	3-53

	Page No.
Cam Position Sensor	4-88
Installation	4-91
Removal	4-88
Cam/Pinion Gear Color Code & Diameter (1999 Models - table)	3-46
Cam/Pinion Gear Color Code & Diameter (2000 Models - table)	3-54
Camshaft Specifications	3-1
Cam Position Sensor and Rotor	
Installation	4-91
Removal	4-88
Capacities	2-1
Carbon Canister	
Hose Routings	4-113
Installation	4-113
Removal	4-112
Charging System	
Alternator	7-15
Battery	7-15
General	7-15
Milliampere Draw Test	7-18
Testing	7-18
Troubleshooting	7-15
Troubleshooting Flowchart	7-16
Voltage Regulator	7-15
Voltage Regulator Bleed Test	7-18
Voltage Regulator Inspection	7-15
Wiring	7-15
Chassis, Torque Values	2-1
Check Engine Lamp	
Behavior	4-4
Clearing Codes	4-10
Diagnostics	4-9
Not Illuminated at Key ON	4-19
On Continuously	4-22
On Continuously (flow chart)	4-24
Checking and Adding Oil	3-30
Checking Cast Rim Runout	2-17
Checking Engine Oil	3-30
Checking Fuel Pressure	4-33
Chin Fairing	2-96
Installation	2-96
Removal	2-96
Cleaning, Shop Practices	1-3
Clearing Trouble Codes	4-10
Clutch Cable-Lower	
Assembly/Installation	2-83
Removal/Disassembly	2-82
Clutch Hand Control	
Assembly/Installation	2-83
Removal/Disassembly	2-82
Clutch Pack	
Assembly	6-15
Removal/Disassembly	6-11
Clutch Release Mechanism	
Adjustment	1-29
Assembly	6-9
Cleaning	6-8
Disassembly	6-8
Clutch Troubleshooting (table)	6-10

	Page No.
Clutch	
Maintenance	1-28
Replacing Transmission Fluid	1-28
Specifications	6-1
Code 11-See Trouble Code 11	4-43
Code 13-See Trouble Code 13	4-47
Code 14-See Trouble Code 14	4-52
Code 15-See Trouble Code 15	4-56
Code 16-See Trouble Code 16	4-60
Code 23/32-See Trouble Code 23/32	4-64
Code 24/25-See Trouble Code 24/25	4-68
Code 33-See Trouble Code 33	4-71
Code 35-See Trouble Code 35	4-74
Code 44-See Trouble Code 44	4-77
Code 52/53/54/55-See Trouble Code 52/53/54/55	4-81
Code 56-See Trouble Code 56	4-82
Codes	
Checking	4-4, 4-8
Clearing	4-8, 4-10
Fuel Injection (table)	4-15
Multiple	4-5
Compression Test Procedure	3-6
Compression, Definition	2-76
Connecting Rod Bushing	3-28
Connecting Rod Races, Lapping	3-65
Connecting Rod Specifications (table)	3-67
Connecting Rod, Specifications	3-2
Countershaft Bearings	
Installation	6-32
Removal	6-32
Countershaft Needle Bearing, Installation	6-33
Countershaft	
Assembly	6-27
Cleaning	6-27
Disassembly	6-24
Crank Pin Size (table)	3-67
Crankcase (1999 Models)	3-60
Crankcase (2000 Models)	3-77
Crankcase Breathing System	3-34
Crankcase Halves (1999 Models)	
Assembly	3-73
Disassembly	3-61
Crankcase Halves (2000 Models)	
Assembly	3-85
Disassembly	3-78
Crankcase (1999 Models)	
Adjustment/Testing	3-60
Assembly	3-71
Cleaning	3-63
Disassembly	3-61
Crankcase (2000 Models)	
Adjustment/Testing	3-77
Assembly	3-85
Cleaning	3-81
Disassembly	3-78
Current and Voltage Output Test	7-19
Cylinder and Piston	
Assembly/Installation	3-29
Cleaning	3-24
Removal/Disassembly	3-23
Cylinder Bore Service Wear Limits (table)	3-25
Cylinder Bore Sizes (table)	3-26

	Page No.
Cylinder Head	
Assembly	3-20
Cleaning	3-15
Disassembly	3-14
Installation	3-21
Removal	3-12
Specifications	3-2
Cylinder Leakage Test	3-7
Cylinder	
Boring and Honing	3-26
Checking Gasket Surface	3-24
Fitment to Piston	3-26
Measuring Cylinder Bore	3-25
Specifications	3-2

D

Damping, Definition	2-76
Data Link	4-6
DDFI, Sensors	4-94
Deutsch Electrical Connectors	7-59
Diagnosing Smoking Engine/High Oil Consumption	3-7
Diagnostic Notes, Definition	4-13
Dimensions	2-1
Drive Belt	
General	6-6
Installation	6-7
Removal	6-6
Drive/Transmission, Torque Values	6-2
DVOM, Wiggle Test	4-12
Dynamic Digital Fuel Injection	4-1

E

ECM	4-86
Connections (table)	4-87
Installation	4-86
No Power-See Fuel Injection	4-32
Removal	4-86
Electric Starter System-see STARTER	5-2
Electrical Connectors	
Amp Multilock	7-61
Deutsch	7-59
Electrical System, Specifications	7-1
Electronic Control Module-See ECM	4-86
Emissions Controls	
General	4-111
Hose Routing	4-113
Installation	4-112
Removal	4-112
Troubleshooting	4-111
Engine Lubrication System, Changing Oil/Filter ...	3-30
Engine Lubrication System, Checking/Adding Oil ..	3-30
Engine Main Bearing Races, Lapping (1999 Models)	3-71
Engine Main Bearing Races, Lapping (2000 Models)	3-85
Engine Oil	1-6
Engine Oil (table)	1-6
Engine Oil Filter, Changing	1-18
Engine Oil, Checking	1-17
Engine Temperature Sensor-See ET Sensor	4-94

Engine	
Adjustment/Testing	3-6
Compression Test Procedure	3-6
Cylinder Leakage Test	3-7
General	3-5
Installation	3-10
Misfire	4-39
Misfire (flow chart)	4-41
Specifications	3-1
ET Sensor	4-94
Installation	4-94
Removal	4-94
Evaporative Emissions Control, Calif. Models	4-111
Exhaust Header	
Assembly/Installation	2-89
Removal/Disassembly	2-86
Exhaust System	
Assembly/Installation	2-88
Removal/Disassembly	2-86

F

Filter, Fuel	4-102
Final Drive, Specifications	6-1
Fitment	
Cylinder to Piston	3-26
Pinion Bearings (1999 Models)	3-67
Pinion Bearings (2000 Models)	3-81
Piston Rings	3-26
Rod Bearings (1999 Models)	3-66
Sprocket Bearings (1999 Models)	3-67
Sprocket Bearings (2000 Models)	3-81
Fluid Requirements	1-6
Flywheel End Play (1999 Models)	3-60
Flywheel End Play (2000 Models)	3-77
Flywheel End Play Shims (2000 Models - table) ...	3-77
Flywheel End Play Spacers (1999 Models - table) .	3-60
Flywheel Washers, Replacement (1999 Models)...	3-65
Flywheels (1999 Models)	
Assembly	3-71
Disassembly	3-63
Specifications	3-3
Flywheel/Connecting Rod Assembly (2000 Models)	
Disassembly	3-81
Specifications	3-3
Footrests (1999 Models)	
Installation	2-90
Removal	2-90
Footrests (2000 Models)	
Installation	2-91
Removal	2-91
Fork Oil, Changing	1-39
Fork Stem	
Adjustment	1-41
Assembly/Installation	2-65
Cleaning	2-65
Removal/Disassembly	2-65
Frame	
Installation	3-10
Removal	3-8
Free Running Current Draw Test	5-12

	Page No.
Front Brake Caliper (1999 Models)	2-25
Assembly	2-26
Cleaning	2-26
Disassembly	2-25
Installation	2-27
Removal	2-25
Front Brake Caliper (2000 Models)	2-45
Assembly	2-46
Cleaning	2-46
Disassembly	2-45
Installation	2-46
Removal	2-45
Front Brake Line (1999 Models)	
Installation	2-29
Removal	2-29
Front Brake Line (2000 Models)	
Installation	2-49
Removal	2-49
Front Brake Master Cylinder (1999 Models)	
Assembly	2-23
Cleaning	2-23
Disassembly	2-22
Installation	2-24
Removal	2-22
Front Brake Master Cylinder (2000 Models)	
Assembly	2-43
Cleaning	2-43
Disassembly	2-42
Installation	2-44
Removal	2-42
Front Brake Switch (1999 Models)	2-29
Front Brake Switch (2000 Models)	2-49
Front Fender, Removal/Installation	2-93
Front Fork Bearings, Maintenance	1-40
Front Fork Oil	1-6
Front Fork	
Assembly	2-62
Cleaning	2-62
Disassembly	2-60
General	2-60
Installation	2-64
Removal	2-60
Front Forks	
Changing Oil	1-39
Settings	1-38
Front Wheel (1999 Models)	
Assembly	2-9
Cleaning	2-8
Disassembly	2-8
Installation	2-10
Removal	2-8
Front Wheel (2000 Models)	
Assembly	2-12
Cleaning	2-11
Disassembly	2-11
Installation	2-13
Removal	2-11
Fuel	1-6
Fuel Filter	4-102
Removal/Installation	4-102

	Page No.
Fuel Injection	4-1
Check Engine Lamp	4-3
Code Types	4-5
Components	4-1
Diagnostic Check (flow chart)	4-17
Diagnostic Tips	4-13
Diagnostics	4-3
Engine Cranks/No Start	4-25
Engine Cranks/No Start (flow chart)	4-27
Engine Starts Hard (table)	4-14
Fuel Pressure (flow chart)	4-36
Idle Speed	4-38
Job/Time Code Values	4-13
Misfire	4-39
Misfire (flow chart)	4-41
No ECM Power	4-30
No ECM Power (flow chart)	4-32
No Start	4-3
Performance Problems (table)	4-14
Poor Performance	4-3
System Diagram	4-2
Trouble Codes (table)	4-15
Troubleshooting Background	4-1
Typical Scan Values (table)	4-14
Fuel Injectors, Repair	4-106
Fuel Pressure (flow chart)	4-36
Fuel Pressure Regulator	4-104
Fuel Pressure, Test	4-33
Fuel Pump	4-103
Installation	4-104
Removal	4-103
Repair	4-103
Specifications (table)	4-103
Fuel Tank Cover	2-97
Installation	2-97
Removal	2-97
Fuel Tank	
Cleaning	4-98
Disassembly/Assembly	4-98
Installation	4-99
Pressure Test	4-99
Removal	4-97
Fuel Tank Vent Valve	
General	4-100
Installation	4-100
Removal	4-100

G

Gas Tank-See Fuel Tank	4-98
Gasoline	1-6
Gasoline/alcohol Blends	3-5
GAWR Rating	2-1
Gear Ratios	6-1
Gear Shaft Specifications (1999 Models - table)	3-47
Gear Shaft Specifications (2000 Models - table)	3-55
Gearcase Cover and Cam Gears (1999 Models)	3-44
Assembly/Installation	3-50
Cleaning	3-45
Removal/Disassembly	3-44

	Page No.
Gearcase Cover and Cam Gears (2000 Models) . . .	3-52
Assembly/Installation	3-58
Cleaning	3-53
Removal/Disassembly	3-53
Gearcase, Specifications	3-3
GVWR Rating	2-1

H

Hammers, Safety	1-3
Handlebar Switches	
Installation	7-41
Removal	7-40
Handlebars	
Adjustment	1-47
Installation	2-85
Removal	2-85
Headlamp Bulb, Removal	7-34
Headlamp	
Adjustment	1-48
Alignment	1-48
Installation	7-35
Removal	7-34
High Oil Consumption	3-7
Horn	
Installation	7-54
Removal	7-54
Troubleshooting	7-55
Hose Routing, Emissions Controls	4-113
Hydraulic Lifters (2000 Models)	
Cleaning and Inspection	3-42
General	3-42
Installation	3-43
Removal	3-42

I

Idle Speed, Adjustment	1-44
Ignition Coil	
Alternative Tests	4-92
General	4-92
Installation	4-93
Primary Circuit Test	4-92
Removal	4-93
Resistance Specifications	7-1
Secondary Circuit Test	4-92
Troubleshooting	4-92
Ignition Rotor	
Installation	4-91
Removal	4-88
Ignition Switch	
IGN Position	7-5
OFF Position	7-5
P Position	7-5
Ignition Timing	
Checking	1-45
Static	1-45
Ignition/Headlamp Key Switch	
General	7-5
Installation	7-6
Removal	7-5

Page No.

Indicator Light, Oil Pressure	3-33
Indicator Markers (table)	7-5
Injectors, Fuel	4-106
Inline Fuel Filter-See Fuel Filter	4-102
Instrument Support	2-84
Installation	2-84
Removal	2-84

L

Lapping	
Connecting Rod Races (1999 Models)	3-65
Engine Main Bearing Races (1999 Models)	3-71
Engine Main Bearing Races (2000 Models)	3-85
Valve Faces and Seats	3-19
Low Fuel Level Sensor	4-104
Lubricant, Primary Drive/Transmission	1-6
Lubrication System	3-30
Lubrication, Force-feed System	3-5
Lubrication, Winter	3-30

M

Main Drive Gear	
Assembly	6-31
Disassembly	6-31
Installation	6-31
Removal	6-30
Mainshaft 5th Gear Ball Bearing, Installation	6-33
Mainshaft Bearings	
Installation	6-32
Removal	6-32
Mainshaft	
Assembly	6-27
Cleaning	6-27
Disassembly	6-24
Manifold-See Throttle Body and Manifold	4-105
Measurements, Piston	3-26
Milliampere Draw Test	7-18
Mount, Oil Filter	3-39
Muffler	
Assembly/Installation	2-88
Removal/Disassembly	2-86

N

Neutral Indicator Switch	6-20
General	7-56
Removal/Installation	7-56
Testing	7-56

O

Oil Filter Mount	
Assembly	3-39
Cleaning	3-39
Disassembly	3-39
General	3-39
Oil Filter, Changing	1-18

	Page No.
Oil Grades (table)	1-6, 1-17
Oil Hose Routing, General	3-31
Oil Pressure	3-33
Oil Pressure Indicator Switch	3-33
Oil Pressure Signal Light	3-33
Troubleshooting (table)	3-33
Oil Pump	
Assembly/Installation	3-38
Cleaning	3-38
General	3-36
Removal/Disassembly	3-37
Specifications	3-3
Oil Tank	
Assembly/Installation	3-32
Removal/Disassembly	3-32
Oil, Engine	1-6
Oiling System Diagram	3-35
Oxygen Sensor	4-94
Installation	4-94
Removal	4-94

P

Pinion Bearings, Fitment (1999 Models)	3-67
Pinion Bearings, Fitment (2000 Models)	3-81
Pinion Gear Color Code & Diameter (table)	3-54
Pinion Gear Identification (1999 Models)	3-45
Pinion Gear Identification (2000 Models)	3-53
Pinion Shaft Bearing Selection (1999 Models - table)	3-70
Pinion Shaft Bearing Selection (2000 Models - table)	3-85
Pinion Shaft Bearings, Specifications	3-3
Piston Rings, Fitment	3-26
Piston	
Assembly/Installation	3-29
Cleaning	3-24
Measuring	3-26
Removal/Disassembly	3-23
Specifications	3-2
Pliers/Cutters/Prybars, Safety	1-3
Preload Adjustment	1-36
Preload, Definition	2-76
Primary Chain Adjuster	
Installation	6-4
Removal	6-4
Primary Chain Tension (table)	1-34
Primary Chain	
Adjustment	1-35
Freeplay	1-34
General	6-3
Installation	6-4
Maintenance	1-34
Removal	6-3
Primary Chain/Drive, Removal/Disassembly	6-13
Primary Cover	
Installation	6-5
Removal	6-3
Primary Drive Lubricant	1-6
Primary Drive	
Assembly	6-15
Specifications	6-1

	Page No.
Primary Drive/Clutch	6-10
Assembly	6-15
General	6-10
Inspection/Repair	6-14
Installation	6-16
Removal/Disassembly	6-11
Punches/Chisels, Safety	1-3
Push Rod Selection (table)	3-21

R

Race Diameter and Crank Pin Size (1999 Models - table)	3-67
Race Diameter and Crank Pin Size (2000 Models - table)	3-82
Ratchets and Handles, Safety	1-4
Rear Belt	
Adjustment	1-31
Deflection	1-31
Maintenance	1-30
Rear Brake Caliper (1999 Models)	2-34
Assembly	2-35
Cleaning	2-34
Disassembly	2-34
Installation	2-35
Removal	2-34
Rear Brake Caliper (2000 Models)	2-53
Assembly	2-54
Cleaning	2-53
Disassembly	2-53
Installation	2-54
Removal	2-53
Rear Brake Line (1999 Models)	
Installation	2-38
Removal	2-37
Rear Brake Line (2000 Models)	
Installation	2-57
Removal	2-56
Rear Brake Master Cylinder (1999 Models)	2-31
Assembly	2-32
Cleaning	2-32
Disassembly	2-31
Installation	2-32
Removal	2-31
Rear Brake Master Cylinder (2000 Models)	2-50
Assembly	2-51
Cleaning	2-51
Disassembly	2-50
Installation	2-51
Removal	2-50
Rear Brake Pedal, Height (1999 Models)	1-20
Rear Brake Pedal, Height (2000 Models)	1-25
Rear Brake Switch (1999 Models)	
Installation	2-38
Removal	2-37
Rear Brake Switch (2000 Models)	
Installation	2-57
Removal	2-56
Rear Fender	
Installation	2-94
Removal	2-94
Rear Preload	1-36

	Page No.
Rear Shock Absorber	2-74
Installation	2-74
Removal	2-74
Rear Shock, Settings	1-38
Rear Wheel	
Assembly	2-15
Cleaning	2-15
Disassembly	2-15
Installation	2-15
Removal	2-14
Rebound, Definition	2-76
Recommended Tire Pressures	2-1
Regulator	
Fuel Pressure	4-104
Specifications (Voltage)	7-1
Voltage	7-23
Removal from Storage	1-49
Repair Notes	1-1
Repair Procedures	1-2
Replacement Procedures	1-2
Rider Sag	2-76
Right Transmission Case Bearings	
Installation	6-33
Removal	6-33
Rim Runout	2-17
Rocker Arm, Specifications	3-2
Rocker Arms and Bushings	3-16
Rod Bearings, Fitment (1999 Models)	3-66
Routing, Oil Hose	3-31

S

Safe Operating Maintenance	1-1
Safety	
Air Tools	1-3
Hammers	1-3
Pliers/Cutters/Prybars	1-3
Punches/Chisels	1-3
Ratchets and Handles	1-4
Screwdrivers	1-3
Sockets	1-4
Storage Units	1-4
Tools	1-3
Wrenches	1-3
Scanalyzer Icon, Flow Charts	4-13
Scanalyzer	
Cartridge	4-6
Data Link	4-6
Diagnostics	4-6
Installation	4-6
Menus	4-7
Wiggle Test	4-12
Screwdrivers, Safety	1-3
Seat (1999 Models)	2-102
Installation	2-102
Removal	2-102
Storage	2-102
Seat (2000 Models)	2-103
Installation	2-103
Removal	2-103
Storage	2-103

Secondary Drive Belt	
General	6-6
Installation	6-7
Maintenance	1-30
Removal	6-6
Sensor, Low Fuel Level	4-104
Sensors	4-94
Servicing a New Motorcycle	1-1
Shift Drum Bushing	
Installation	6-32
Removal	6-32
Shift Drum Needle Bearing, Installation	6-33
Shifter Forks and Drum	
Assembly	6-22
Cleaning	6-21
Disassembly	6-21
Shifter Pawl, Adjustment	6-34
Shims, Flywheel End Play (2000 Models)	3-77
Shop Practices	1-1
Cleaning	1-3
Side Stand	
Assembly/Installation	2-106
General	2-106
Removal/Disassembly	2-106
Signal Light, Oil Pressure	3-33
Smoking Engine	3-7
Sockets, Safety	1-4
Solenoid	
Hold-In Test	5-13
Pull-In Test	5-13
Return Test	5-13
Spacers, Flywheel End Play (1999 Models)	3-60
Spark Plug Cables	
General	7-7
Inspection	7-7
Installation	7-7
Removal	7-7
Spark Plugs	
Maintenance	1-42
Specifications	7-1
Type	1-42
Specifications	
Capacities	2-1
Camshaft	3-1
Chassis	2-1
Dimensions	2-1
Drive/Transmission	6-1
Electric Starter	5-1
Electrical	7-1
Engine	3-1
GAWR	2-1
GVWR	2-1
Tire Pressure	2-1
Tires	2-4
Transmission Gear Ratios	6-1
Weight	2-1
Spring Preload	2-75
Sprocket Bearings, Fitment (1999 Models)	3-67
Sprocket Bearings, Fitment (2000 Models)	3-81
Sprocket Cover	
Assembly/Installation	2-90
Removal/Disassembly	2-90
Sprocket Shaft Bearing, Specifications	3-3
Squat, Setting	1-36

	Page No.
Starter Current Draw Test	5-11
Starter Interlock Troubleshooting (table)	7-8
Starter Interlock	
General	7-8
Testing/Replacement	7-13
Starter Relay	
General	5-2
Removal/Installation	5-11
Testing	5-11
Starter Solenoid	
Assembly	5-19
Disassembly	5-19
General	5-19
Testing	5-13
Starter System Testing	5-11
Starter	
Activation Circuits	5-8
Assembly	5-17
Diagnostics/Troubleshooting	5-9
Disassembly/Repair	5-14
Installation	5-18
Operation	5-2
Removal	5-12
Service Wear Limits	5-1
Specifications	5-1
System Diagnosis	5-6
Torque Values	5-1
Troubleshooting (table)	5-4
Static Ignition Timing	1-45
Stator Check	7-19
Stator, Removal/Disassembly	7-21
Steering Head Bearing Grease	1-6
Steering Head Bearings	
Lubrication	1-40
Maintenance	1-40
Steering Head Lock	2-67
Installation	2-67
Removal	2-67
Stone Guard	
Installation	2-95
Removal	2-95
Storage Units, Safety	1-4
Storage	
Battery (1999 Models)	1-12
Battery (2000 Models)	1-15
General	1-49
Removal	1-49
Stripping Motorcycle For Engine Repair	3-8
Suspension Adjustments	2-77
Spring Preload	2-77
Troubleshooting	2-77
Suspension Problems	
Front (table)	2-78
General (table)	2-77
Rear (table)	2-78
Suspension Settings	1-38
Suspension Theory	
Definitions	2-76
General	2-76
Suspension, Adjustment	1-38

	Page No.
Swingarm	2-69
Assembly	2-71
Cleaning	2-70
Disassembly	2-70
Installation	2-71
Removal	2-69

T

Tail Section	2-100
Assembly	2-102
Cleaning	2-102
Disassembly	2-100
Installation	2-102
Removal	2-100
Tappets/Lifters, Specifications	3-3
Throttle Body and Manifold	4-105
Installation	4-107
Removal	4-105
Repair	4-106
Throttle Cables	
Adjustment	1-44
Idle Adjustment	1-44
Maintenance	1-44
Throttle Control	
Assembly/Installation	2-80
Cleaning	2-80
Removal/Disassembly	2-80
Throttle Position Sensor-See TP Sensor	4-96
Tip Sensor-See Bank Angle Sensor	4-95
Tire Fitment	
Tubeless Aluminum P/M Wheels (table)	2-4
Tubeless Cast Wheels (table)	2-4
Tire Pressure	2-1
Tire Pressures (table)	1-27
Tires	
Adjustment	2-20
Checking Tire Lateral Runout	2-19
Checking Tire Radial Runout	2-19
Cleaning	2-18
General	2-18
Inspection	2-18
Installation	2-19
Maintenance	1-27
Removal	2-18
Wheel Balancing	2-20
Wheel Weights	2-20
Tool Safety	1-3
Torque Values	
Chassis	2-1
Drive/Transmission	6-2
Starter	5-1
Total Current Draw Test	7-18
TP Sensor	4-96
Calibration	4-96
Installation	4-96
Removal	4-96
Transmission Case	
Cleaning	6-20
General	6-19
Removal	6-19
Transmission Fluid, Type	1-6, 1-28
Transmission Gear Ratios	6-1

